

Assembly instructions

1. Remove the screws indicated with the arrows.


2. Replace the removed screws with the new screws (part #4), aluminium sleeve part #3) and metal bars (parts #2) according to the attached drawing. Put the metal bars (parts #2) in the right positions according to the drawing.

- 3. Assemble the sliders and the screws according to the drawing (parts #1, #5, #6).
- 4. Assemble the screws #5 and the sliders with the metal bars #2.

We suggest to use the threadlocker to make sure that the screws do not get loose.

This product is entirely produced in the European Union. This product is a professional accessory to be used on the race track. Renner LTD takes no responsibility for any damages occurred despite of using protective accessories. For more information go to www.renner-moto.com

Assembly scheme (both sides)



NO	PART	LEFT SIDE	RIGHT SIDE
1	Slider	L = 65 mm	L = 65 mm
2	Steel bar		
3	Sleeve	d =22mm, t=20mm	d =22mm, t=5mm
4	Screw	M10, I = 70 mm	M10, I = 60 mm
5	Screw	M10	M10
6	Washer		